



deye.md

MANUAL DE UTILIZARE

Sistem Stocare Deye GE-F60 HV 61.44 kWh IP55

Model / familie: GE-F60 61.44 Kwh


Copertă de distribuție adăugată de deye.md. Manualul oficial al producătorului Deye este reprodus integral, fără modificări, începând cu pagina următoare.


Sursă oficială Deye

<https://deye.com/product/ge-f60new/>


Distribuție și suport în Moldova · deye.md

Installation instructions for GE-F60 cable shield







a
x1




b
x1




c
x1




d
x1



e
x1




f
x1




g
x1




h
x 34




First, after installing the cabinet and inverter, remove the cover plate.




Fix a, b and c to the cabinet with h.



Use a Phillips screwdriver of appropriate length to tighten a total of 13 screws. You are advised to route the cables from the inverter to the battery cabinet through the left exit, and the cables from the inverter to the PV and signal cables through the right exit. You are advised to route the multi-core cables through the bottom of the protective cover, and secure the cables to the protective cover using cable ties.



Fix d, g and f to the cabinet with h.



A total of 20 screws should be tightened with a Phillips screwdriver of appropriate length.